

How does the spray booth work?

The spray booth extracts air from the room and moves it through specialist filters. These filters remove aerosol particles and fumes. The filtered air is then removed through a series of tubes and released outside.

The spray booth has a sensor and should automatically turn on when you enter the room. If, while using the booth, the room suddenly goes quiet it has turned off. Move your arm until the sensor sees you and the booth turns on again.

[Next Page: How do I use the spray booth?](#)

[Return to: Spray booth menu](#)

Revision #5

Created 29 April 2020 11:07:56 by Roisin de Cogan

Updated 13 May 2020 13:02:16 by Roisin de Cogan