Preparing to cut on Silhouette vinyl cutter software

1. Open your .DXF and group all the elements with CMD+G to retain their position and move into an appropriate location, this should not be too close to the edge.



2. If needed, navigate to the transform panel (1) and then to the scale options (2), this can be used to adjust the size of your print incase it has been changed during import.



3. Navigate to the Send tab. Settings should be set Cut, Vinyl Matte blade protrusion 1



Next Page: Video Guides - Printer setup & Transfer process

Return to: Vinyl cutter Information

Revision #14
Created 15 June 2017 11:24:13
Updated 21 September 2022 10:00:36 by Roisin de Cogan